Repair of timber and reinstatement of lime plaster finish to exterior east wall

The removal of the damaged wall render has now been completed to reveal the original timbers of the east wall to the property.

Timber repairs: There are only 3 very minor areas which require a repair which entails a removal of decayed timber and spice a new oak timber part. The specific details of location and size are denoted on the document headed ‘East Wall Timber Plan’.

Lime Plaster Application: The listed building consent required a statement towards the mixture details of lime plaster

Stage 1: A scratch coating of around 10mm thickness will be applied. This will be a lime and coarse aggregate mix. This will be left to dry for at least 10 days.

Stage 2: A float coat of around 10mm thickness will be applied. This will be a lime and coarse aggregate mix and finished to leave a smoother coating. This will be left to dry and set for around 10 days

Stage 3: A skim coat of around 4mm will be applied. This will be a lime and fine aggregate mix to leave a decorative finish. This will be left to dry and set for at least 4 days prior to painting with lime wash exterior paint.